

Boulder Hockey Shield Zero mask mounting instructions and chin cup adjustment.

Description  
1. Mounting clips face up. Screws included fit into the posts inside the front of the helmet.  
2. Snap buckle affixes to the male posts on both sides of the helmet.



Adjustment buckle loop around outside cage frame bar, then strap snaps to side of helmet with snap buckle.



Chin cup attached to lower vertical bars. Left picture chin cup attached to vertical bars. Picture 2, chin cup is floating.

*Note: Both methods the adjustment buckle attaches to outside cage frame edge for proper fit.*

